



<u>RELINER PART #</u>	<u>DESCRIPTION</u>
ANCH 316/ANCH	TYPE 304 STAINLESS TYPE 316 STAINLESS

### ANCHOR INSTALLATION

1. DRILL 3/8" HOLE IN BASE MATERIAL TO THE REQUIRED DEPTH (APPROX 1-1/4" DEEP)
2. BLOW THE HOLE CLEAN OF DUST AND OTHER MATERIAL
3. INSERT THE ANCHOR INTO THE HOLE (LEAD SHIELD OUT)
4. POSITION A SETTING TOOL OR 9/16 SOCKET AGAINST THE ANCHOR OUTER CONE (THE OUTER RIM OF THE TOOL OR SOCKET SHOULD SEAT ONTO THE LEAD SHIELD RIM)
5. USING THE TOOL OR SOCKET, SET THE ANCHOR BY DRIVING THE LEAD SLEEVE OVER THE CONE USING SEVERAL SHARP HAMMER BLOWS. (BE SURE THE ANCHOR IS AT THE REQUIRED EMBEDMENT DEPTH)
6. POSITION THE FIXTURE, INSERT SCREW OR BOLT AND TIGHTEN

<b>RELINER / DURAN, INC.</b>		
9 MATTHEWS DRIVE, UNIT A1/A2 EAST HADDAM, CT 06423 (800) 508-6001 FAX: (877)434-3197		
DESCRIPTION	DATE	SCALE
ANCHOR	2-2-21	NONE
	DRAWING NUMBER ANCH	