



<u>RELINER PART #</u>	<u>DESCRIPTION</u>
WEDGE ANCHOR	TYPE 304 STAINLESS
DOM-WEDGE ANCHOR	TYPE 304 STAINLESS DOMESTICALLY PRODUCED*
316 / WEDGE ANCHOR	TYPE 316 STAINLESS
DOM-316 / WEDGE ANCHOR	TYPE 316 STAINLESS DOMESTICALLY PRODUCED*
	* AMERICAN IRON AND STEEL CERTIFIABLE

WEDGE ANCHOR INSTALLATION

1. DRILL 3/8" HOLE IN CONCRETE UP TO 2-1/2" DEEP
2. CLEAN ALL DEBRIS OUT OF HOLE
3. PLACE NUT ON END OF WEDGE ANCHOR TO PROTECT THREADS AND DRIVE INTO DRILLED HOLE LEAVING AN ADEQUATE AMOUNT EXPOSED TO ALLOW FOR MOUNTING PRODUCTS
4. AFTER PRODUCT MOUNTING, TIGHTEN NUT UNTIL WRENCH RESISTANCE IS FELT (APPROXIMATELY 3 - 4 TURNS AFTER NUT IS SNUGGED UP.

RELINER / DURAN, INC.		
9 MATTHEWS DRIVE, UNIT A1/A2 EAST HADDAM, CT 06423 (800) 508-6001 FAX: (877)434-3197		
DESCRIPTION	DATE	SCALE
WEDGE ANCHOR	2-2-21	NONE
	DRAWING NUMBER WEDGE ANCHOR	